



BOAT BIMINI MISTER WITH EXTERNAL TANK/PUMP STEP BY STEP INSTALLATION GUIDE

The following instructions are designed to help you easily install the Boat Bimini Mister with an External Tank/Pump Option to your Boat Bimini top.

- STEP 1:** Determine the best location for the Misting Tank/Pump (keep in mind it needs to be close enough to the cigarette adapter plug in the boat).
- STEP 2:** Fill tank full of FRESH water only. (Do not move tank by lifting with motor).
- STEP 3:** Carefully un-wind the misting line and route it up to the Boat Bimini top and use the supplied straps to easily attach the misting line to the Bimini.
- STEP 4:** Position the middle mister head in the middle of the Bimini Top. Use the supplied Velcro straps to attach the mister head to the Bimini pole...keep the straps as close to either side of the canvas/head as possible. Then attach other two mister heads with Velcro straps.
- STEP 5:** Make sure the line is pulled tight to prevent sagging.
- STEP 6:** Adjust mister heads to spray downward.
- STEP 7:** Insert the remaining end of line into the pump on the tank. (Shorten line for custom fit).
- STEP 8:** Plug in cigarette adapter plug.

WHEN YOU WANT THE MISTER TO PROVIDE REFRESHING COOLING MIST, TURN ON THE SWITCH ON THE END OF THE CIGARETTE ADAPTER.

**Note: Mister Line should be taken down prior to collapsing Top and tube needs to drain.
Follow these simple steps:**

- STEP 1:** Turn OFF the pump.
- STEP 2:** Disconnect line going to pump by pushing the ring at the mouth of the fitting towards the fitting and simultaneously pull the tube out of it.
- STEP 3:** Let water drain from the tubing.
- STEP 4:** Carefully coil mister line into a 12" diameter loop being careful not to pinch line.

PUT AWAY UNTIL ANOTHER HOT DAY!

Maintenance

Included in your mister kit is an extra mister head. If you notice a head not providing a fine mist, turn off mister and replace head with spare mister head. To disconnect, push the ring at mouth of the fitting toward the fitting and simultaneously push/pull the tube out of it. You may need pliers; be careful not to pinch head or tubing. To clean the head use CLR or Lime Away. Pour a small amount of CLR or Lime Away into a small container enough to cover mister head and follow instructions on bottle for how long to soak. Once head is clean it can be reinserted in the system.

Routine Maintenance

Heads should be routinely cleaned every 3 months or before a long storage using the instructions above, this will prevent the build up of calcium and lime in mister heads.

Questions please refer to website www.mist-er-comfort.com or call (888) MIST 370

**(407) 695-0958
toll free: (888) MIST 370**